

FLEXIPANEL LTD
2, MARSHALL ST, 3RD FLOOR
LONDON W1F 9BB, UK

Notes for Windows Vista Users

Of FlexiPanel Products

USB Installation

Our USB products use the `usbser.sys` driver which was shipped with previous versions of Windows, but not Windows Vista. To install FlexiPanel products, first copy the file `usbser.sys` in the development kit to the `C:\Windows\System32\Drivers` folder. Then ensure you specify the `.inf` file with the `- Vista` suffix, e.g. `USBoot - Vista.inf`.

HyperTerminal

Windows HyperTerminal is used by several of our evaluation guides. It is not shipped with Windows Vista but is available as *HyperTerminal Private Edition*, a free download from www.hilgraeve.com.